

DELTA

DELTA 46H Series Bumper Fog/Driving Light Kit

PART#S 01-9229-50X & 01-9039-50X

INSTALLATION INSTRUCTION

1. Removing the front fascia may make for easier access to the work area.
2. Remove factory fog lights if you have them.
3. Cut out plastic material as marked on photo #3 to allow Delta 46H lights to be retrofitted into light housing in the fascia.
4. Provided is a template for a Hummer H2, however, it should work for any round factory fog light opening.
5. Repeat this procedure for the other light.
6. Install relay in a close proximity of the battery.
7. Connect yellow wire leads running from the harness to prong #87 and #87A on the relay
8. Connect Blue wire lead to prong #85 on the relay.
9. Connect short Black wire lead to prong #86 on the relay.
10. Connect red long wire lead to prong #30 on the relay.
11. Using the sheet metal screw (provided) run short black ground wire terminated with ring connector attach relay to the flat surface under the hood.
12. Run blue wire from relay through the fire wall and into the cab.
13. Install switch in desired location. Connect the blue wire to switch.
14. Ground the switch to any metal surface under dashboard using the short black wire.
15. Energize the switch by splicing into any hot wire under the dash (preferably to low-beam wire).
16. Remove the fuse from the red wire leading from the relay and connect to the positive post on the battery. Now insert the fuse back into the fuse holder.



DELTA TECH INDUSTRIES, LLC - Placentia, CA 92870, U.S.A.

Web: www.deltalights.com E-mail: sales@deltatechindustries.com